

Operating Instructions

Z 200

Hand Knife Sharpening Machine



Operating Instructions

Z200 Hand Knife Sharpening Machine

Manufacturer

ZAHND Schleiftechnik GmbH
Hauptstrasse 34
4142 Münchenstein
Switzerland

Phone +41-61-411 71 11

info@zahnd-schleiftechnik.ch
www.zahnd-schleiftechnik.ch

Documents for machine operator

Operating Instructions

Date of issue of the operating instructions

July 23, 2025

Copyright

The copyright for these operating instructions as well as other documents for the machine operator is held by ZAHND Schleiftechnik GmbH. They are supplied only to customers and operators of our products and belong to the machine.

Without our express permission, these documents may neither be duplicated nor made accessible to third parties, in particular competitor companies.

Table of Contents

1.	Important notes	7
1.1	Preface to the operating instructions	7
1.2	Warnings and symbols in the operating instructions	7
1.3	Warning and mandatory signs and their meaning	8
1.3.1	Warning and mandatory signs on the grinding machine	8
1.3.2	General warning and mandatory signs	8
1.4	Rating plate and machine serial number	9
1.5	Figure and position numbers in the operating instructions	9
2.	Safety	10
2.1	Basic safety instructions	10
2.1.1	Observe notes in the operating instructions	10
2.1.2	Obligation on the part of the operator	10
2.1.3	Obligation on the part of the personnel	10
2.1.4	Hazards involved in handling the grinding machine	10
2.1.5	Malfunctions	11
2.2	Intended use	11
2.3	Warranty and liability	11
2.4	Safety regulations	12
2.4.1	Organizational measures	12
2.4.2	Protective equipment	12
2.4.3	Informal safety measures	12
2.4.4	Selection and qualification of personnel	12
2.4.5	Machine control system	13
2.4.6	Safety measures in normal operation	13
2.4.7	Hazards due to electrical power sources	13
2.4.8	Particular hazard areas	13
2.4.9	Servicing (maintenance, repair) and fault rectification	13
2.4.10	Structural alterations to the grinding machine	14
2.4.11	Cleaning the grinding machine	14
2.4.12	Lubricants/oils and greases	14
2.4.13	Relocation of the grinding machine	14
3.	Description	15
3.1	Intended use	15
3.2	Technical specifications	15
3.3	Functional description	16
3.4	Description of the assemblies	17
3.4.1	Control panel	18
3.4.2	Suction nozzle	18

Table of Contents

4.	Transport	19
4.1	Transport aids	19
4.2	Transport damage	19
4.3	Transport to another installation site	19
5.	Installation	20
5.1	Selection of qualified personnel	20
5.2	Installation site	20
5.3	Supply connections	20
5.4	Settings	20
5.5	Initial start-up of the grinding machine	21
6.	Commissioning	22
7.	Operation	23
7.1	General grinding fundamentals	23
7.2	Switch on the grinding machine	24
7.3	Sharpening hand knives	24
7.4	Deburring and polishing hand knives	26
7.4.1	Deburring and polishing without guide bracket	26
7.4.2	Deburring and polishing with guide bracket	27
7.5	Replacing the grinding wheels	29
7.6	Replacing the polishing disk	31
7.7	Suction Unit	34
8.	Care and maintenance	35
8.1	Cleaning	35
8.1.1	Cleaning agent and lubricant table	35
8.2	Maintenance plan (one-shift operation)	36
9.	Disassembly and disposal	37
9.1	Disassembly	37
9.2	Disposal	37

Table of Contents

10.	Service, spare parts and accessories	38
10.1	Postal address ZAHND general distribution	38
10.2	Service	38
10.3	Wear and spare parts	38
10.4	Accessories	39
10.4.1	Abrasives used etc.	39
11.	Appendix	40
11.1	EU Declaration of Conformity	40

1. Important notes

1.1 Preface to the operating instructions

These operating instructions are intended to make it easy to learn how to use the hand knife sharpening machine, hereafter referred to as the grinding machine, and to properly utilize its features.

These operating instructions contain important notes on how to operate the grinding machine safely, properly and efficiently. Observing these instructions helps to avoid hazards, reduce repair costs and downtimes, and to increase the reliability and service life of the grinding machine.

The operating instructions must be permanently available at the place of use of the grinding machine.

The operating instructions must be read and applied by every person tasked with working with the grinding machine, e.g.:

- transport, installation, commissioning
- operation, including error rectification during operation, as well as
- servicing (maintenance, repair).

Recognized technical standards for safe and professional work must be observed in addition to these operating instructions and the binding accident prevention regulations applicable in the country of use and at the place of use.

1.2 Warnings and symbols in the operating instructions

The operating instructions use the following symbols/designations that must be followed:



The hazard triangle with the signal word "CAUTION" serves as a work safety notice for all work for which there is a risk of personal injury or death.

In these cases, work should be done with special attention and care.



"ATTENTION" is written in places where special attention must be paid to prevent damage or destruction of the grinding machine or its surroundings.



"NOTICE" refers to user tips and especially useful informations.

1. Important notes

1.3 Warning and mandatory signs and their meaning

1.3.1 Warning and mandatory signs on the grinding machine


The following warnings and mandatory signs have been affixed on the grinding machine:



**CAUTION! RISK OF INJURY FROM ABRASIVE PARTICLES
(mandatory sign on the machine front)**

Grinding, polishing and deburring creates abrasive particles that can enter the eyes.

Wearing eye protection is mandatory when carrying out such work.



**CAUTION! PULL OUT THE POWER PLUG BEFORE OPENING!
(mandatory sign on the back of the machine)**

The grinding machine must be separated from the mains supply before the replacement of grinding wheels or polishing disk.

1.3.2 General warning and mandatory signs

The following general mandatory signs must be observed:



CAUTION! RISK OF INJURY FROM KNIFE!

Working with the grinding machine involves grinding knives that could cause serious cut injuries due to their sharpness.

Caution when transporting knives. Use the protective equipment provided by the knife manufacturer. Protective gloves and safety shoes must be worn.

1. Important notes

1.4 Rating plate and machine serial number



Figure 1-1 Rating plate

The rating plate (1-1) is located on the back of the machine.

The machine serial number is located on the rating plate (1-1).

1.5 Figure and position numbers in the operating instructions

If the text makes a reference to a machine component depicted in a figure, the figure and position number will be given in brackets.

Example: (7-13/1) means figure number 7-13, item 1.




Figure 7-13 Removing the used grinding wheels

Remove used grinding wheels (7-13/1) including holding fixture (base body).

2. Safety

2.1 Basic safety instructions

2.1.1 Observe notes in the operating instructions

The basic prerequisite for the safe handling and uninterrupted operation of this grinding machine is knowledge of the basic safety instructions and regulations.

- These operating instructions contain important notes on how to operate the grinding machine safely.
- All persons carrying out work on the grinding machine must follow these operating instructions, in particular the safety notices.
- In addition, the rules and regulations regarding accident prevention at the place of use are to be observed.

2.1.2 Obligation on the part of the operator

The operator is obliged to allow only those persons to work on the grinding machine, who

- are familiar with the occupational safety and accident prevention regulations and have received instruction in handling the grinding machine,
- have read and understood the operating instructions, in particular the section entitled "Safety" and the warning notes, and have provided signed confirmation of this.

The safety-awareness of the personnel at work will be monitored at regular intervals.

2.1.3 Obligation on the part of the personnel

All personnel working on the grinding machine shall be obliged, before starting work, to

- observe basic occupational safety and accident prevention regulations,
- read the operating instructions, particularly the section entitled "Safety" and the warning notes, and provide signed confirmation that they have understood them.

2.1.4 Hazards involved in handling the grinding machine

The grinding machine has been built to the latest technological standards and the recognized rules of technical safety. Nevertheless, its use may result in danger to life and limb of the user or third parties, or damage to the grinding machine or other property.

The grinding machine may be used only:

- for its intended purpose
- in a safe and secure condition.

Malfunctions that may impair safety are to be eliminated immediately.

2. Safety

2.1.5 Malfunctions

If safety-relevant malfunctions occur with the grinding machine, or if the processing behavior indicates that such malfunctions may have occurred, the grinding machine must be stopped immediately and until such time as the malfunction has been found and eliminated.

Allow only authorized trained personnel to eliminate the malfunctions.

2.2 Intended use

The grinding machine is only suitable for sharpening, deburring and polishing hand knives of 70–550 mm in length.

Any other use or use beyond this is not considered as intended. ZAHND Schleiftechnik GmbH is not liable for any damage resulting from this. The risk is borne solely by the user.

Intended use also includes observing all instructions in the operating manual.

ATTENTION

Improper use of the grinding machine exists, for example, if:

- **fixtures are not properly attached.**
- **knives are sharpened/polished in the opposite direction of the cutting edge on the grinding wheels or the polishing disk.**
- **workpieces other than hand knives are ground.**

2.3 Warranty and liability

Warranty and liability claims in case of personal injury or property damage are excluded if such damage is attributable to one or more of the following causes:

- improper use of the grinding machine,
- improper transport, commissioning, operation, and maintenance of the grinding machine,
- operating the grinding machine with defective safety devices, or using improperly attached or malfunctioning safety and protective equipment,
- failure to observe the instructions with regard to transportation, commissioning, operation, maintenance and repair of the grinding machine,
- unauthorized structural alterations to the grinding machine,
- unauthorized modification, e.g. of the drive conditions (output and speed),

2. Safety

- failure to monitor machine parts that are subject to wear, and
- use of unapproved replacement and wear parts.

Use only original replacement and wear parts. If externally purchased parts are used, it is not guaranteed that they have been designed and manufactured to meet the requirements in terms of stress and safety.

2.4 Safety regulations

2.4.1 Organizational measures

Inspect all available safety devices regularly.

Observe prescribed intervals for recurring maintenance work or as specified in the operating instructions!

2.4.2 Protective equipment

Before every commissioning of the grinding machine, ensure that all protective equipment is properly mounted and in functional condition.

Protective equipment may only be removed after the grinding machine has come to a complete stop and has been secured against restarting.

When attaching spare parts, the protective equipment must be attached by the operator as stipulated.

2.4.3 Informal safety measures

The operating instructions must be permanently available at the place of use of the grinding machine. In addition to the operating instructions, the generally applicable as well as locally relevant accident prevention regulations must also be made available and observed.

All safety alert symbols and hazard warnings on the grinding machine must be complete and clearly legible.

2.4.4 Selection and qualification of personnel

Only trained and instructed personnel may work on the grinding machine. Observe the legally permitted minimum age!

The responsibilities of personnel with respect to commissioning, operation, maintenance, and repair must be clearly specified.

Personnel still undergoing training or instruction may only work on the grinding machine under the permanent supervision of an experienced person!

2. Safety

2.4.5 Machine control system

Only trained and instructed personnel are permitted to switch on and operate the machine.

2.4.6 Safety measures in normal operation

Do not operate the machine in any unsafe manner. Only operate the grinding machine if all the safety devices are installed and fully functional.

At least once per shift (or per day), check the grinding machine for externally visible damage and proper functioning of the safety devices.

Immediately report any changes present (including those of the operating behavior) to the responsible office or person. If necessary, immediately shut down the grinding machine and secure it against restart.

Before you switch on the grinding machine, ensure that no one can be injured by the start-up of the machine.

In the event of a malfunction, immediately stop the grinding machine and secure it against restart. Rectify malfunctions immediately.

2.4.7 Hazards due to electrical power sources

Work on electrical systems or operating materials may only be performed by a qualified electrician, in accordance with electrical regulations.

Defects, such as damaged cables, cable connections, etc. must be immediately rectified by an authorized specialist.

2.4.8 Particular hazard areas

In the area of the grinding wheels and polishing disk there is a hazard of pinching and of drawing in e.g. clothing, fingers and hair. Suitable personal protective equipment must be worn.

2.4.9 Servicing (maintenance, repair) and fault rectification

Maintenance work is to be carried out on schedule by trained personnel. Inform operating personnel before beginning repair work. Designate a supervisor responsible for this.

For all service work, the grinding machine is to be disconnected from the power supply and secured against accidental restart. Remove power plug. Secure repair area as necessary.

After completing maintenance work and rectifying any faults, install all safety devices and verify that they are fully functional.

2. Safety

2.4.10 Structural alterations to the grinding machine

Do not make any changes, additions or conversions to the grinding machine without the approval of the manufacturer. This also applies to the installation and setup of safety devices.

Any conversion work requires the written permission from ZAHND Schleiftechnik GmbH.

Immediately replace machine parts that are not in perfect condition.

Use only original replacement and wear parts. If externally purchased parts are used, it is not guaranteed that they have been designed and manufactured to meet the requirements in terms of stress and safety.

2.4.11 Cleaning the grinding machine

Properly handle any cleaning agents and materials used and dispose of them in an environmentally-friendly manner.

Dispose of the wear parts and replacement parts in a safe and environmentally-friendly manner.

2.4.12 Lubricants/oils and greases

When using oils and greases, follow the safety regulations applicable to the product. Comply with the special regulations for the food areas.

2.4.13 Relocation of the grinding machine

Disconnect the grinding machine from any external power supply, even in the event of a minor change of location. Before restarting the grinding machine, connect it properly to the power supply.

3. Description

3.1 Intended use

The Z200 Hand Knife Sharpening Machine can be used to sharpen, deburr and polish hand knives with a length of 70–550 mm.

3.2 Technical specifications

Height	245 mm
Width	385 mm
Depth	185 mm
Space requirements (DxW)	approx. 500 x 600 mm
Weight	approx. 11 kg
Power supply*	1x 230 V
Mains frequency*	50/60 Hz
Output*	0.25 kW
Power consumption*	0.38 kW
Current consumption*	1.72 A
Back-up fuse	16 A
Operating noise level (measured A-weighted emission sound pressure level at the workplace LpA)**	approx. 70 dB (A)
Diameter grinding wheels	125 mm
Diameter polishing disk	150 mm
Speed of polishing disk/grinding wheels (50 Hz)	2800 rpm
Operating noise level polishing disk/grinding wheels	approx. 76 db (A)
Grinding angle	30°

*) This information may change depending on the electrical power supply.

**) Two-digit sound emission value according to EN ISO 4871 (measurement uncertainty KpA. 3 dB (A)). Emission sound pressure level according to EN ISO 11201. A hand knife from Giesser was sharpened.

3. Description




Figure 3-1 Dimensions in mm

3.3 Functional description

The Z200 Hand Knife Sharpening Machine can be used to sharpen, deburr and polish hand knives with lengths of 50 to 550 mm.

The machine is equipped with a double grinding wheel set and a polishing disk.

3. Description

3.4 Description of the assemblies



Figure 3-2 General view of grinding machine

- 1 Control panel
- 2 Grinding unit
- 3 Dirt tray
- 4 Polishing disk
- 5 Guide bracket

3. Description

3.4.1 Control panel



Figure 3-3 Control panel

- 1 "ON / OFF" switch

3.4.2 Suction nozzle



Figure 3-4 Dirt tray bin with suction nozzle

- 1 Suction nozzle for industrial vacuum cleaner

4. Transport



When transporting, observe the local applicable safety and accident prevention regulations.

Only transport the grinding machine with the machine feet facing downwards.

4.1 Transport aids

For transporting and for setting up of the grinding machine, only use adequately dimensioned transport aids.

4.2 Transport damage

If damage is detected during acceptance of the delivery, immediately inform the distributor and the forwarding agent. If necessary, an independent expert must be called in immediately.

Remove packaging and fastening straps. Remove the shipping straps on the grinding machine. Dispose of packaging in an environment-friendly manner.

4.3 Transport to another installation site

For transport to another installation site, ensure that the space requirements are fulfilled (see Chapter 3.2).

A permissible electrical connection must be provided at the new installation site. The grinding machine must stand firmly and securely.



Work on the electrical unit is only to be carried out by an authorized specialist. Observe the locally applicable safety and accident prevention regulations.

5. Installation

5.1 Selection of qualified personnel



We recommend having the installation work on the grinding machine carried out by the trained KNECHT ??? personnel.

We are not liable for any damage resulting from improper installation.

5.2 Installation site

When determining the installation site, bear in mind the space required for installation as well as maintenance and repair work on the grinding machine (see Chapter 3.2).

5.3 Supply connections

The grinding machine is provided ready to connect with the corresponding connection cable.

5.4 Settings

ZAHND Schleiftechnik GmbH will configure the various components as well as the electrical system before delivery.

ATTENTION

Unauthorized alterations to the preset values are not permitted and can damage the grinding machine.

5. Installation

5.5 Initial start-up of the grinding machine

Place the grinding machine at the installation site on a level table or base. The table height should be approx. 70–80 cm max.

The ideal working height is achieved when the machine operator has to raise his shoulder only slightly when sharpening (rolling) the knife tip.

Completely install and inspect the protective equipment before commissioning.



CAUTION

Have all protective equipment checked for proper functioning by authorized trained personnel before commissioning the machine.

6. Commissioning



CAUTION

All work may only be carried out by authorized specialist personnel.

Observe the locally applicable safety and accident prevention regulations.

There is a risk that hands, hair and clothing may be pulled in while the grinding machine is switched on.

Serious injuries are possible. Wear personal protective equipment.

Connect the machine plug to the socket provided on site (1x 230 V, 16 A).



Figure 6-1 Control panel

Turn on the grinding machine by pressing the "ON/OFF" switch (6-1/1).

The grinding wheels and polishing disk rotate.



Figure 6-2 Checking rotating direction

Check the rotating direction.

The direction arrows (6-2/1) indicate the direction of rotation of the grinding wheels and polishing disk.

After ensuring the prescribed direction of rotation, turn off the grinding machine.

ATTENTION

If the direction of rotation is not correct, immediately stop the machine, secure it and notify the ZAHND service.

7. Operation

7.1 General grinding fundamentals

To sharpen the cutting edge which has become blunt, the metal must be removed from the knife.

To do so, grind the knife up to the cutting edge until a small burr appears.

The burr is gently removed with the polishing disk under moderate pressure. To do this, move the knife from the knife handle to the knife tip alternately to the left and right over the polishing disk (left – right – left – right – left, etc.). Repeat the process approx. 6 times until the knife edge is burr-free and smooth.

As it is not only the sharp cutting edge, but also the long service life that define a blade, the cutting edge angle is another important indicator of a blade's performance.

In theory, the smaller the cutting edge angle, the higher the service life. In practice, however, it seems that a cutting edge angle that is too small results in the cutting edge breaking off and thus becoming blunt.

The cutting edge angle is therefore between 25° and 35°. For cutting edge angles below 15°, the cutting edge is so unstable that it snaps with the smallest resistance. For a cutting edge angle of more than 40°, the cutting edge is extremely stable but it loses sharpness very fast.

In essence: The profile and cutting edge angle stipulated by the manufacturer must be maintained.

7. Operation



CAUTION

All work may only be carried out by authorized specialist personnel.

Observe the locally applicable safety and accident prevention regulations.

There is a risk that hands, hair and clothing may be pulled in while the grinding machine is switched on.

Serious injuries are possible!

7.2 Switch on the grinding machine



Figure 7-1 Control panel

Switch on the grinding machine using the "ON/OFF" switch (7-1/1).

The grinding wheels and polishing disk rotate.

7.3 Sharpening hand knives

NOTE

Knives must be cleaned before sharpening.



Figure 7-2 Sharpening hand knives

To sharpen the knife, place it in the knife guide as close as possible to the handle (see figure 7-2). The knife guide is magnetic and helps to guide the knife precisely.

Align the blade horizontally and pull slowly and with equal pressure along the grinding wheel towards the tip.

In the area of the knife tip, move the handle upwards according to the shape of the knife.

7. Operation



Figure 7-3 Sharpening hand knives

Repeat the process alternately on the right and left side until a fine burr appears.

Then deburr and polish the hand knife on the polishing disk as described in Chapter 7.4.

After the sharpening process is completed, switch of the grinding machine using the "ON/OFF" switch (7-1/1).

7. Operation

7.4 Deburring and polishing hand knives



There is a risk that hands, hair and clothing may be pulled in while the grinding machine is switched on.

Never hold the cutting edge against the running direction of the polishing disk. Serious injuries are possible!

Deburring and polishing create abrasive particles that can enter the eyes. Wear safety glasses. Wear a face mask.

7.4.1 Deburring and polishing without guide bracket



Figure 7-4 Folding the guide bracket upward

Fold the guide bracket (7-4/1) upward.




Figure 7-5 Applying the polishing paste

Switch on the grinding machine.

Apply polishing paste (7-5/1) briefly to the running polishing disk (7-5/2) with little pressure.

7. Operation



Figure 7-6 Polishing hand knives

To deburr/polish, place the knife on the polishing disk (7-6/1) at an angle of approx. 30°. The cutting edge should not run across, but at an angle to the polishing disk.

The burr is gently removed under moderate pressure.

To do this, move the knife from the knife handle to the knife tip alternately to the left and right over the polishing disk (left – right – left – right, etc.). Repeat the process approx. 4–6 times until the knife edge is burr-free and smooth.

After the polishing process is completed, switch of the grinding machine using the “ON/OFF” switch.

NOTE

Polish the blade only until the burr is removed.

Apply polishing paste to the polishing disk again after approx. 5–7 knives.

After sharpening, deburring and polishing the knives must be cleaned and disinfected.

7.4.2 Deburring and polishing with guide bracket




Figure 7-7 Applying the polishing paste

Fold the guide bracket upward.

Switch on the grinding machine.

Apply polishing paste (7-7/1) briefly to the running polishing disk (7-5/2) with little pressure.

7. Operation



Figure 7-8 Folding down the guide bracket

Fold down the guide bracket (7-8/1).



Figure 7-9 Polishing hand knives

Place the knife on the guide bracket (7-9/2) for deburring/polishing.

The burr is gently removed under moderate pressure.

To do this, move the knife from the knife handle to the knife tip alternately to the left and right over the polishing disk (left – right – left – right – left, etc.). Repeat the process approx. 4–6 times until the knife edge is burr-free and smooth.

After the polishing process is completed, switch off the grinding machine using the “ON/OFF” switch.

NOTE

Polish the blade only until the burr is removed.

Apply polishing paste to the polishing disk again after approx. 5–7 knives.

After sharpening, deburring and polishing the knives must be cleaned and disinfected.

7. Operation

7.5 Replacing the grinding wheels



CAUTION

For all work on the grinding machine, observe the locally applicable safety and accident prevention regulations as well as instructions in the "Safety" and "Important notes" section of the operating instructions.

Disconnect the power plug before changing the grinding wheels.

Never turn on the machine without the covers on. Risk of injury!



Figure 7-10 Unscrewing the knurled nuts

Unscrew the two knurled nuts (7-10/1) counter-clockwise.



Figure 7-11 Removing the protection hood

Remove the protection hood (7-11/1) by lifting it upwards.

NOTE

Always replace grinding wheels in pairs!

7. Operation




Figure 7-12 Unscrewing the knurled nut

Hold the grinding wheels firmly and unscrew the knurled nut (7-12/1) **counterclockwise**.




Figure 7-13 Removing the used grinding wheels

Remove the used grinding wheels (7-13/1) including the holding fixture (base body).




Figure 7-14 Mounting a new pair of grinding wheels

Place a new pair of grinding wheels on the holding fixture (7-14/1) and place everything together on the shaft.

Retighten the knurled nut (7-12/1).

Rinse the protection hood under running water.

Reattach the protection hood and secure it with the two knurled nuts (7-10/1).

ATTENTION

Only original abrasives from ZAHND Schleiftechnik GmbH are permitted to be used.

ZAHND Schleiftechnik GmbH assumes no responsibility for the use of non-original abrasives.

7. Operation

7.6 Replacing the polishing disk



CAUTION

For all work on the grinding machine, observe the locally applicable safety and accident prevention regulations as well as instructions in the "Safety" and "Important notes" section of the operating instructions.

Disconnect the power plug before changing the polishing disk.

Never turn on the machine without the covers on. Risk of injury!




Figure 7-15 Loosening the polishing disk cover

Loosen the screw (7-15/1) on the rear of the machine using a T20 Torx screwdriver.



Figure 7-16 Loosening the polishing disk cover

Loosen the screw (7-16/1) on the front using a T20 Torx screwdriver.

7. Operation




Figure 7-17 Removing the polishing disk cover

Remove the polishing disk cover (7-17/1) by lifting it upwards.




Figure 7-18 Loosening the polishing disk

Loosen the clamping screw of the polishing disk (7-18/1) **clockwise** (left-hand thread) using a 13 mm ring spanner.

Remove the used polishing disk (7-18/2).

NOTE

The clamping screw (7-18/1) of the polishing disk has a left-hand thread.



Figure 7-19 Removing the clamping screw and clamping flange

Remove the clamping screw and clamping flange (7-19/1).

7. Operation




Figure 7-20 Replacing the polishing disk

Place a new polishing disk (7-20/1) with clamping flange on the shaft and tighten.

NOTE

The polishing disk must be mounted so that the inscription "NKG" is on the outside.




Figure 7-21 Guide screws polishing disk cover

Rinse the polishing disk cover under running water.

Reattach the cover. Make sure that the left side wall of the cover is seated in the guides of the two guide screws (7-21).

Secure the cover with the two screws (7-16/1) and (7-15/1).

ATTENTION

The polishing disk cover must be firmly seated in the guide screws, otherwise the polishing disk will rub against the cover.

Only original abrasives from ZAHND Schleiftechnik GmbH are permitted to be used.

ZAHND Schleiftechnik GmbH assumes no responsibility for the use of non-original abrasives.

7. Operation

7.7 Suction Unit




Figure 7-22 Dirt tray with suction nozzle

The dirt tray (7-22/1) of the Z200 is equipped as standard with a suction nozzle (7-22/2) for commercial industrial vacuum cleaners.

NOTE

The machine may only be operated with suction (industrial vacuum cleaner).



Figure 7-23 Connection for industrial vacuum cleaner

On the rear of the machine there is a connection (7-23/1) for commercial industrial vacuum cleaners.

NOTE

The standard scope of delivery includes a socket (7-16/1) and a plug for commercial industrial vacuum cleaners.

8. Care and maintenance



For all work on the grinding machine, observe the locally applicable safety and accident prevention regulations as well as instructions in the "Safety" and "Important notes" section of the operating instructions.

8.1 Cleaning

The machine must be cleaned with a soft cloth and care spray after each grinding process, otherwise the grinding abrasion is difficult to remove.

After cleaning, we recommend the products listed below for care of the machine (see also the table of cleaning agents and lubricants in chapter 8.1.1).

ATTENTION

The grinding machine must not be sprayed with water.

8.1.1 Cleaning agent and lubricant table

Cleaning / Lubrication work	Interflon	WÜRTH	SHELL	EXXON Mobil	OEST
Cleaning and care of machine parts	Dry Clean Stainless Steel	Stainless steel care spray	Risella 917	Marcol 82	New Process Multispray
Lubrication of threads and sliding surfaces	Fin Grease	Multi-pur- pose grease	Gadus S2 V1002	Mobilith SHC 100	IXELON GOC 190

8. Care and maintenance

8.2 Maintenance plan (one-shift operation)

Interval	Assembly	Maintenance task
Daily	Knife guide unit	Clean under running water, afterwards spray with care spray.
	Entire grinding machine	Clean with a soft cloth and care spray.
Weekly	Polishing disk cover	Dispose of the polishing abrasion and clean the polishing disk cover under running water, afterwards spray with care spray.
Annually		Contact the service department of ZAHND Schleiftechnik GmbH.

9. Disassembly and disposal

9.1 Disassembly

All operating materials must be disposed of properly.

Secure moving parts against slippage.

Disassembly must be conducted by a qualified specialist.

9.2 Disposal

After the machine has reached the end of its service life, it must be disposed of by a qualified specialist. In exceptional situations, and after consultation with ZAHND Schleiftechnik GmbH, the machine may be returned.

Operating materials (e.g. grinding wheels, polishing disks etc.) must be disposed of correctly.

10. Service, spare parts and accessories

10.1 Postal address ZAHND general distribution

KNECHT Maschinenbau GmbH
Witschwender Straße 26
88368 Bergatreute
Germany

Phone +49-7527-928-0
Fax +49-7527-928-32

mail@knecht.eu
www.knecht.eu

10.2 Service

Service line:

For address, see postal address

service@knecht.eu

10.3 Wear and spare parts

If you need spare parts, please use the spare parts list provided with the machine. Please place your order using the format described below.

When ordering, please always provide: (example)

Machine type	(Z200)
Machine number	(271)
Designation of assembly	(Base plate)
Designation of single part	(Grinding wheels set of 2)
Item number (position number)	(29)
Drawing number (article number)	(412B-00-0020)
Quantity	(1 pc)

We are always happy to answer any questions.

10. Service, spare parts and accessories

10.4 Accessories

10.4.1 Abrasives used etc.

Designation	Dimensions	Grain	Article number	Notes
Grinding wheels set of 2	diam. 125 mm	150	412B-00-0020	Installed on delivery
Polishing disk	diam. 150 mm		412Z-01-0030	Installed on delivery
Polishing paste	95x30 mm		412Z-02-0010	Included in scope of delivery

ATTENTION

Only original abrasives, wear and spare parts from ZAHND Schleiftechnik GmbH are permitted to be used.

ZAHND Schleiftechnik GmbH assumes no responsibility for the use of non-original parts.

If you require abrasives or other accessories, please contact our sales staff and distributors, or KNECHT Maschinenbau GmbH directly.

Thank you for your confidence!

11. Appendix

11.1 EU Declaration of Conformity

in accordance with EU Directive 2006/42/EU

- Machinery 2006/42/EU
- Electromagnetic Compatibility 2014/30/EU

We hereby declare that the machine designated as follows, due to its construction and design, as well as the version we placed on the market, complies with the relevant fundamental safety and health requirements of the applicable EU Directive.

In case of a modification of the machine not agreed with us, this declaration loses its validity.


Designation of machine:	Hand Knife Sharpening Machine
Model designation:	Z200
Machine number:	from no. 271
Applicable harmonized standards, in particular:	DIN EN 12100-1 DIN EN 12100-2 DIN EN 60204-1 ISO 13857 DIN EN 349
Responsible for documentation:	Andreas Doerr (State-certified technician) Phone +49-7527-928-81 a.doerr@knecht.eu
Manufacturer:	ZAHND Schleiftechnik GmbH Hauptstrasse 34 4142 Münchenstein Switzerland

A complete technical documentation is available. The operating instructions document for the machine is available in its original version and in the native language of the user.

The validity of the declaration expires in the event of changes to the legal requirements.

Münchenstein, July 23, 2025

ZAHND Schleiftechnik GmbH



Hanspeter Zahnd
CEO

ZAHND Schleiftechnik GmbH

Hauptstrasse 34 · 4142 Münchenstein · Switzerland · T+41-61-4117111
info@zahnd-schleiftechnik.ch · www.zahnd-schleiftechnik.ch